



Battery Fitting Instructions for **Digital Air Pressure Gauge**

Step 1 – Locate 2 x AAA batteries supplied in packaging with digital gauge.

Step 2 – Pull back rubber surround on digital gauge body to reveal location of battery cover.

Step 3 – Remove battery cover and fit batteries, ensuring correct polarity of positive and negative terminals.

Step 4 – Refit battery cover and ensure it is clipped in correctly.

Step 5 – Refit rubber surround to gauge body. Gauge is now ready to use.